PAGE 1

IQOS®

This symbol indicates that caution is required when operating the product.

ENGLISH

SAFETY WARNINGS AND INSTRUCTIONS

PLEASE READ AND KEEP THESE INSTRUCTIONS

The Safety Warnings and Instructions included in this document cannot cover all the possible conditions and situations which could occur. Caution and care must be exercised when using or maintaining any personal electronic product. Only charge this product indoors. Only charge your product by using an approved IQOS® Power Adapter. Do not drop this product or subject it to strong shock. Keep away from children at all times and ensure that they do not play with this product. This product is not intended for use by persons with reduced physical, sensory or mental capabilities or lack of knowledge, unless they have been given supervision or instruction to use the product in a safe way and understand the hazards involved.

PAGE 2

Do not use this product under the following circumstances:

- Where the use of electronic devices is prohibited.
- On or near heat sources, i.e. radiators or fires.
- If it is damaged, tampered with or broken.
- If it has been exposed to excessive heat or moisture.
- If the IQOS® Holder's cap is removed.
- If it becomes wet or is immersed in any liquid (this does not apply to the IQOS® Holder cap).
- If its batteries appear to be leaking. If the liquid comes in contact with the skin or eyes, wash with large amounts of water and seek medical advice.
- If it is operating in an erratic manner.
- If the battery in the Holder or Pocket Charger is unusually hot to the touch.

To reduce the risk of injury, always use this product in accordance with the manufacturer's instructions and follow these precautions:

- Do not touch this product if it becomes wet or immersed in any liquid.
- Never attempt to touch the Heater Blade.
- Do not attempt to open, modify or repair any component of this product or to replace any of the components or batteries. This product contains no user-serviceable parts.
- Never use this product in places where flammable materials, liquids and gases are present.

ATTENTION

IQOS® works exclusively with Marlboro HeatSticks®. Never use IQOS® with a conventional cigarette or similar products, or with tobacco sticks or accessories not approved by the manufacturer. Do not remove a HeatStick while in use. Marlboro HeatSticks® are single use only and should never be re-used, lit with a match, lighter or any other flame source.

PAGE 3

⚠ IMPORTANT SAFETY INFORMATION

⚠ WARNING **Battery Risk**

IQOS® is powered by sealed Lithium-ion (Li-ion) batteries. Under normal conditions of use, the battery is sealed. If battery fluid leaks, follow these precautions:

- If you swallow the fluid, seek medical attention immediately. Do not induce vomiting or ingest food or drink.
- If the fluid is inhaled, get fresh air and seek medical attention.
- In case of contact with skin, wash hands and do not touch eyes.
- In case of contact with eyes, immediately flush with running water for at least 15 minutes and seek medical attention.
- Only use the IQOS® USB Power Adapter for charging the IQOS® Pocket Charger
- Do not attempt to touch the IQOS® USB Power Adapter if it is wet.

⚠ CAUTION **Hot Aerosol Risk**

- When using IQOS® under hot and humid weather conditions, the water in the aerosol makes the aerosol temperature feel very hot.
- To help avoid this sensation, store your Marlboro HeatSticks® in a cool, dry place. Do not expose the product to high humidity conditions or direct sunlight. Do not use IQOS® during hot conditions or in periods of high humidity.
- If you experience discomfort, stop using the product and seek medical attention.

For any questions or concerns, please contact your local Customer Care (1-877-438-4767).
For more information please go to www.GetIQOS.com

INFORMATION FOR DISPOSING OF IQOS® 3



This symbol on the product or on its packaging indicates that this product and its individual parts (including batteries) must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment.

Your IQOS® Device contains a Lithium-ion rechargeable battery. When discarded, it must be recycled or disposed of properly in accordance with state and local requirements. Do not crush the battery (e.g., such as in a trash compactor). Do not dispose of any part of this product in fire or flame. For further information on recycling and disposal of the battery call 1-877-2-RECYCLE (1-877-273-2925) or contact your local waste management officials.

PAGE 4

Supplier's Declaration of Conformity – 47 CFR § 2.1077 Compliance Information

FCC Compliance Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception (a) when charging, which can be determined by disconnecting and then reconnecting the device to the charging source, or (b) when in use, which can be determined by drawing on and ceasing to draw on the device, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- If the equipment is connected to the charger, then connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Cease to use (i.e., cease drawing on) the device.

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Use only for intended purposes.

Unique Identifiers - A1404 and A1504

Responsible Party – U.S. Contact Information
Philip Morris USA
1-877-GET-IQOS (1-877-438-4767)
http://www.GetIQOS.com

TECHNICAL DATA

IQOS® 3 Holder Model: A1404
Battery type: Li-ion rechargeable battery
Input: 5V ⎓ 1.6A

IQOS® AC Power Adapter
Model: S52A21, S21A20, S21A22, S21A23, S21A25, S21A27,S21A27
Input: 100V-240V~ 50/60HZ 0.3A
Output: 5V ⎓ 2A

Micro USB Type C Cable

IQOS® 3 Pocket Charger
Model: M0002
Battery type: Li-ion rechargeable battery
Input: 5V ⎓ 2A

49.H991